






ACCESSORIES



CONTROL PANEL



1. Function selector knob
2. Minute minder
3. Thermostat knob
4. Thermostat indicator light (red)

Oven functions table	
Function	Description of function
0 OVEN OFF	-
 LAMP	To switch on the oven light.
 BOTTOM HEATING ELEMENT	<ul style="list-style-type: none"><li>• To finish cooking fruit or cheese cakes or to thicken sauce.</li><li>• To thicken sauces.</li></ul> Use this function for the last 10/15 minutes of cooking time.
 STATIC	<ul style="list-style-type: none"><li>• To cook any food</li><li>• Preheat the oven to the required cooking temperature and place the food inside as soon as the red thermostat light turns off.</li><li>• It is advisable to use the second or third level.</li></ul>
 GRILL	<ul style="list-style-type: none"><li>• To cook meat (smoked bacon, steaks, sausages, etc.) and for making toast.</li><li>• Preheat the oven for 5 min. with the door closed.</li><li>• For best results, leave the oven door open when grilling.</li><li>• Arrange food on the wire shelf. When cooking meat, to avoid spatters of fat and smoke, pour a little water into the drip tray.</li><li>• Turn the food during grilling.</li></ul>

SWITCHING ON THE OVEN

- Turn the selector knob to the required function.
- The oven light switches on.
- Turn the thermostat knob clockwise to the required temperature. The red thermostat indicator light switches on; when the required cooking temperature is reached it will turn off.

At the end of cooking time:





















- Turn the knob to "0".

MINUTE MINDER











The minute minder is a mechanical timer that allows a setting between 1 and 60 minutes.

- Turn the knob clockwise to the required cooking time.
  - Once the set time has elapsed, an acoustic signal will sound.
- To reset the acoustic signal, turn the knob all the way round and then turn it back to the required cooking time.

COOKING TABLES

FOOD	Function	Preheating	Level (from the bottom)	Temperature (°C)	Cooking time (min)
<b>Meat</b>					
Lamb, Kid, Mutton		X	2	200	90-110
Veal, Beef, Pork		X	2	200	90-110
Chicken, Rabbit, Duck		X	2	200	70-80
Turkey (3-5 kg)		X	2	210	160-180
Goose (2 kg)		X	2	210	100-130
<b>Fish (1 kg)</b> Gilt-head, Bass, Tuna, Salmon, Cod		X	2	200	60-80
<b>Fish (&lt;1kg. - cutlets)</b> Sword Fish, Tuna		X	2	190	50-60
<b>VEGETABLES</b> Peppers, tomatoes, roast potatoes		X	2	190	50-60
<b>Sweets - pastries</b> Raising cakes		X	2	180	40-50
Filled pies (with cheese)		X	2	190	60-90
Tarts		X	2	190	40-50
Apple strudel, crêpes		X	2	200	50-60
Biscuits, sponge rings, shortbread		X	2	180	20-30
Choux buns, sweet sponge rolls		X	2	180	35-45
Savoury pies, filled fruit pies, e.g. Pineapple, Peach		X	2	200	50-60
Lasagna, potatoes au gratin, cannelloni, pasta timbales		X	2	200	40-50
Bread		X	2	210	30-40
Pizza		X	2	225	15-20
Vol-au-vents		X	2	210	20-30
Soufflés		X	2	200	40-50

COOKING TABLE FOR GRILL FUNCTION

FOOD	Function	Preheating	Level (from the bottom)	Temperature (°C)	Cooking time (min)
Toast		X	3-4	200-225	10-15
Sirloin steak		X	3-4	200-225	30-40
Cutlets		X	3-4	200-225	30-40
Sausages		X	3	200-225	30-40
Pork chops		X	3	200-225	30-40
Fish (cutlets)		X	3	200-225	30-40
Chicken legs		X	3	200-225	40-50
Kebabs		X	3	200-225	40-50
Spare ribs		X	3	200-225	40-50
Chicken halves		X	3	200-225	40-50

**N.B.:** Cooking times and temperatures are approximate only.